



TECHNICAL DATA

accessories

Who:

phoenix gold
tech department

What:

how to build a
custom RDDP
(Remote Data
Display Panel).

Example: You want to monitor the battery voltage inside your amplifier and duplicate the Power-on, Overload and Thermal LEDs.

You will need a PG# HPC8 connector (RJ45 style connector), 6 or 8 conductor cable with a maximum conductor diameter of .040 inches and three standard 2 volt LEDs.

Use a suitable crimping tool for RJ45 style connectors (PG# CT8P).

