

COAXIAL LOUDSPEAKER OWNER'S MANUAL



FOR MODELS:

RSd3

RSd4

RSd5

RSd6

RSd6.5

RSd460

RSd570

RSd690



Congratulations on your purchase of high quality Phoenix Gold audio electronics. At Phoenix Gold our highest concern is musical reproduction. We appreciate that you chose our product. Through years of engineering expertise, hand craftsmanship and critical testing procedures, we have created a wide range of products to give your system all the clarity and richness you deserve.

Please read your warranty and retain your receipt and original carton for possible future use.

Great product and competent installations are only one piece of the puzzle when it comes to your system. Make sure that your install is using only the best installation accessories. Phoenix Gold manufactures everything from RCA cables and speaker wire to power/ground cable and battery connectors. With proper installation and accessories your system will sound the best that it can.

For more information about Phoenix Gold electronics, speakers and accessories please visit www.phoenixgold.com



WARRANTY

LIMITED WARRANTY SPEAKERS (USA)

Phoenix Gold warrants this product to be free of defects in materials and workmanship for a period of one (1) year from the original date of purchase.

This warranty is not transferable and applies only to the original purchaser from an authorized Phoenix Gold dealer. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction, Phoenix Gold will (at its discretion), repair or replace the defective product

with new or remanufactured product at no charge. Damage caused by the following is not covered under warranty: accident, misuse, abuse, product modification or neglect, failure to follow installation instructions, unauthorized repair attempts, misrepresentations by the seller. This warranty does not cover incidental or consequential damages and does not cover the cost of removing or reinstalling the unit(s). Cosmetic damage due to accident or normal wear and tear is not covered under warranty.

IF YOU NEED SERVICE ON YOUR PHOENIX GOLD PRODUCT:

Phoenix Gold encourages product owners to first contact their original Phoenix Gold reseller to determine whether the issue can be resolved without sending the product back to Phoenix Gold.

If a return is necessary, the reseller will contact Phoenix Gold to obtain authorization for the return. All returns require a Return Authorization number from Phoenix Gold before shipping the product to Phoenix Gold's service facility. If a product owner is unable to return a product to the original reseller, the owner can contact Phoenix Gold directly to obtain a Return Authorization number. Units returned to Phoenix Gold without an RA number may be subject to refusal or delays.

All warranty returns should be sent to Phoenix Gold's Product Service facility freight-prepaid and must be accompanied by proof of purchase (a copy of the original sales receipt).

Non-defective items received may be returned freight-collect. Customer is responsible for shipping charges and insurance when sending the product to Phoenix Gold. Freight damage on returns is not covered under warranty.

FOR SERVICE INFORMATION IN THE U.S.A. PLEASE CALL:

Phoenix Gold Customer Service: (503) 286-9300 or (800) 950-1449 during normal business hours (8:30 AM – 5:00 PM Pacific Standard Time)

AFTER A RETURN AUTHORIZATION NUMBER HAS BEEN ISSUED, THE PRODUCT MAY BE SHIPPED TO THE FOLLOWING ADDRESS:

Phoenix Gold Product Service 9269 N. Bradford St. Portland, Or 97203

PHOENIX GOLD INTERNATIONAL, INC

9300 North Decatur St. Portland, OR 97203 (do not send product for repair to this address)

INTERNATIONAL WARRANTIES:

Products purchased outside the United States of America are covered only by that country's Authorized Phoenix Gold reseller and not by Phoenix Gold International, Inc. Consumers needing service or warranty information for these products must contact that country's reseller for information.

Use the following area record basic information about your purchase.

Model Number ___

Serial Number (if available) _

Date of Purchase ___

Store/Reseller Purchased from —






BASIC INSTALLATION

Selecting the placement of your new RSd Coaxial speakers could be as easy as using the existing factory locations or may require you to create a new location. Speaker placement in the door, dash, or rear deck is the most common. See your local Phoenix Gold Dealer for additional location and mounting assistance.

DOORS / REAR DECK

- Many vehicles already have factory locations (Figure 1.) to house the "DROP IN" feature of the RSd Coaxial line. If no existing locations are available or are not used, check the desired location for adequate cutout area and any depth obstructions. Make sure to allow sufficient clearance for window tracks, structural braces, trunk lid springs, etc.
- Assuming enough area and depth is available, use the provided template and trace the speaker cutout and mounting holes onto the

- surface of the mounting location.
- 3. If the mounting surface is not structurally strong enough to accommodate screws, (i.e. plastic, cardboard) use the provided speed clips which will act as a nut for the supplied screws.
- 4. Always provide water protection if not supplied in the vehicle. We suggest using a rain shield or equivalent. If in doubt, please contact your Phoenix Gold Dealer.



SPEAKER INSTALLATION WITHOUT GRILL

When installing your new coaxial speakers in the factory locations there may not be room enough to use the provided RSd grills. Don't worry, these speakers perform just as well behind the factory grill. Please make sure to use the foam mounting gasket as shown in figure 1. This will ensure an air tight seal for your RSd speakers.

Mounting the speaker in a custom application using

SPEAKER INSTALLATION WITH GRILL (grills are supplied with all models except RSd3)

For more custom applications, or cases where the factory grill will not be used, a high excursion protective grill has been provided. Please read the section above on installation for concerns about custom installations.




Figure 2.

RSd SPEAKERS COAXIAL LOUDSPEAKER OWNER'S MANUAL



FEATURES:

PERFORMANCE DESIGN

Developed and CAE/CAD optimized by Phoenix Gold from the ground up to set new standards in performance.

INJECTION MOLDED ALUMINUM PLATED GRAINED POLYPROPYLENE CONE

Injection molded to be very light and rigid for excellent signal tracking.

BUTYL RUBBER SURROUND

Advanced butyl rubber surround is more rugged than foam, resists moisture and UV, and is extremely well damped.

FLAT LINEAR ROLL SPIDER (on select models)

Reduces distortion and provides maximum voice coil centering.

INTERWOVEN TINSEL LEADS

Tinsel leads woven directly into the spider provide added strength and reliability.

RIGID POWDER COATED STEEL FRAME

OPTIMIZED MAGNET/MOTOR STRUCTURE

Results in high efficiency and clarity of sound reproduction.

SPECIFICATIONS: Due to continual product improvement, all specifications subject to change without notice.

T/S Parameters	RSd3	RSd4	RSd5	RSd6	RSd6.5	RSd460	RSd570	RSd690
Re (Dcr)	3.6	3.6	3.6	3.6	3.6	3.6	3.6	3.6
Fo (Hz)	109.5	104.2	91.5	84.3	65.7	109.7	77.1	60.8
Sd (SqM)	0.0037	0.0055	0.0088	0.0121	0.0133	0.0076	0.0154	0.0211
BL (TM)	2.704	3.258	4.081	4.093	4.925	3.835	4.235	5.299
SPLo (dB)	83	86	88	88	88	87	88	89
Qms	3.76	4.12	5.93	5.39	6.07	3.69	7.01	5.25
Qes	1.22	1.13	0.94	1.17	0.78	1.15	1.23	0.98
Qts	0.92	0.88	0.81	0.96	0.69	0.88	1.04	0.83
Vas (cu M)	0.00116	0.00201	0.00443	0.00718	0.0116	0.0025	0.0113	0.217
Cms (uM/N)	584.70	460.10	400.80	346.90	462.80	308.60	337.80	342.60
Mms (gms)	3.61	5.07	7.54	10.27	12.68	6.82	12.62	19.98
Power Handling (Minimum RMS/Peak)	5W/60W	5W/80W	5W/100W	5W/100W	5W/120W	5W/80W	5W/100W	5W/160W
VC (in)	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Frequency Response (Hz)	100-10K	80-20K	70-20K	65-20K	65-20K	100-20K	65-20K	55-20K
Impedance (ohm)	4	4	4	4	4	4	4	4
Cut Out Dimension (mm)	80	93	115	125	142	144w x 89h	182w x 127h	217w x 154h
Mounting Depth (mm)	50	55	61	65	73	56	65	83

